ICY DOCK™

MB016 CPF/CKDF

Multi-Bay Backplane Module

INSTALLATION GUIDE

• Content Description

• Removable Hard Drive Enclosure Rack Kit

• Accessory bag
6#-32 Flat Head screw x 12
6#-32 Truss Head screw x 8
Miniature key x 2
Key x 2（MB016CKDF only）



• Installation Guide

• Failure indicators description

A. MB016CKDF

a.1-When housing temperature exceeds the original temperature setting, the Failure Indicator will indicate Amber color and the alarm buzzer sounds.

a.2-When fan stops、slows down or disconnected, the Failure Indicator will indicate Red color and the alarm buzzer sounds.

a.3-Deactivate the alarm buzzer by pressing the Reset button.

a.4-The Failure Indicator will still indicate Amber (or Red) and will not revert until the failure is properly repaired.

B. MB016CPF

b.1-When housing temperature exceeds the original temperature setting, the Failure Indicator will indicate Red color.

b.2-The Failure Indicator will still indicate Red and will not revert until the failure is properly repaired.

650026 V2004.07

• Back-plane view



• Display front panel indicators



1. HDD1 Power / Failure Indicator
2. HDD1 Access Indicator
3. HDD2 Power / Failure Indicator
4. HDD2 Access Indicator
5. HDD3 Power / Failure Indicator
6. HDD3 Access Indicator
7. Fan failure / Overheat Indicator
8. Reset Switch
9. ID Display

1. HDD1 Power / Failure Indicator
2. HDD1 Access Indicator
3. HDD2 Power / Failure Indicator
4. HDD2 Access Indicator
5. HDD3 Power / Failure Indicator
6. HDD3 Access Indicator
7. Overheat Indicator